



Wander Management Solutions



Secure
Care
Products LLC



Solutions for all your Wander Management Needs

Secure Care Products can help you enhance the safety of your patients or residents with our line of selective monitoring equipment. Take a look at some of the unique feature sets of our product and see the value and performance we build into our products.



- Battery back-up on all our panels ensures no programming memory loss in the event of a power failure
- Exit panel LED indicators are exceptionally bright and use universal symbols avoiding language specific instructions
- Exit panels and mounting boxes can be either flush or surface mounted on your walls and are made entirely of a high-impact polymer to resist damage
- Transmitters can be placed on either ankle or wrist
- Selectable programming features that provide you better value and allow you to customize the operation of your door or entire building depending on local code requirements
- ETL listed to both UL 294 Access Control and UL 1069 Hospital Signaling and Nurse Call equipment standard, along with being NFPA 101 Life Safety Code compliant when Secure Care listed components and cabling are used
- All of these features are standard with our Secure Care systems

The **1st** to provide a
Wandering Resident Solution

Universal Product:

Features:

- No on board antenna in door panel, detection zones created by external receivers
- Individually tune each receiver directly from the software
- External receivers determine frequencies, not the door panel
- Change system frequency without overhaul of hardware
- Change door panel codes from software



Benefits:

- **Cost Savings:** with unforeseen environmental changes or the addition of new technology, it is possible to swap a frequency without an overhaul of hardware.
- **Future Proofing:** with Universal Product with Secure Care Software 3.0 you can interchange frequencies.
- **Flexibility:** With password restricted access users can manage their system security settings directly from the software. In addition the detection zones for transmitters can be tuned to create custom protected exits.
- **mVision:** with Universal Product with Secure Care Software 3.0 your facility has the option of using our mobile application.



Door GUARDIAN® Software

- Quick, straightforward, and easy to use.
- Near real-time status
- Virtual environment supported
- Clear visual display of floor plans and exits
- Simple resident transfers
- Multiple-floor monitoring capabilities
- Displays detailed alarm and alert information including transmitter ID; resident's name, picture and room number; and event location.
- Quick report generation at your fingertips including alarm and alert histories, resident activity logs, staff response times, expired transmitter list, and transmitter reorder information.





Secure[®]
Care
Products LLC

The Best in Wander Management Solutions Since 1979

Features & Operation of the 135DE & SC-40DE:



- Allows for normal traffic flow
- Alarms or locks door when a monitored resident attempts to exit
- User-programmable escort codes
- Non-volatile memory
- Program to lock/unlock at specified times
- DE (delayed egress) feature complies with NFPA Life Safety Code 101
- Emergency battery backup
- Reports events to Secure Care's nurse console or PC
- Interfaces with a variety of dry contact driven devices such as magnetic locks, nurse call, pagers, CCTV, Secure Care nurse consoles, fire alarm systems, elevators, etc.

Locations Used:

Main entrances with high visitor traffic or exits at which a wanderer/resident may attempt to "tailgate".

Features & Operation of the 135ID & SC-40ID:



- Includes all features listed for the 135DE/SC-40DE (above) plus...
- Displays residents by name, location, and transmitter number
- The Door GUARDIAN[®] Software logs detailed resident and event data can be archived for future report generation
- ID based solutions allow staff to react more efficiently by having the added knowledge of the exact resident(s) to look for in the case of an event

Locations Used:

Ideal for facilities with a large population of residents requiring monitoring to assist with reducing staff response time. This robust system can identify resident(s) by name, location, and transmitter number in the event of an alert or alarm. When interfaced with Door GUARDIAN[®] Software, the resident's photo will also be displayed.

Features & Operation of the 500DE:

- Programmable to lock a door 24/7
- Automatic arm & disarm at programmable times
- Does not use transmitters
- Customizable 3-digit codes for easy access and escort
- Reports events to the Secure Care nurse console or PC
- DE (delayed egress) feature complies with NFPA Life Safety Code 101
- Emergency battery backup
- Interfaces with a variety of dry contact driven devices such as magnetic locks, nurse call, pagers, CCTV, Secure Care nurse consoles, fire alarm systems, elevators, etc.



Locations Used:

Doors that are off-limits to residents such as stairwell doors, employee break areas, and loading docks.

Features & Operation of the 135:

- Allows for normal traffic flow
- Alarms when a monitored resident attempts to exit a monitored door
- Customizable 3-digit codes for easy access and escort
- Reports events to Secure Care's nurse console or PC
- Non-volatile memory
- Emergency battery backup
- Interfaces with a variety of dry contact driven devices such as magnetic locks, nurse call, pagers, CCTV, Secure Care nurse consoles, fire alarm systems, elevators, etc.



Locations Used:

Doors that do not require our Smartloc magnetic lock such as automatic doors, elevators, high traffic staff doors leading to kitchen and laundry areas or a second door in a path of egress that is already locked.

4 & 8 Channel Nurse Consoles



In addition to the distinctive alarm at the exits, a variety of nurse consoles are available to ensure that no alarm goes unnoticed.

- Unique sound
- Flashing, very bright LED's to indicate which exit is in alarm
- Can be installed at multiple locations
- Interfaces to remote sounders, strobe lights or other relay-driven devices



Learn how you can take your facility into the future of Senior Care with



&



Be Connected Anywhere You Go

By adding the mVision mobile application to your solution you can customize communication to your staff about real time alarms and alerts directly to mobile devices.



Increase Staff Safety

The ENVisionIT staff badge features a duress button that will not only alert their need for assistance but their real time location as well.

Seamlessly Integrate with Door GUARDIAN Wander Prevention

RTLS can help you customize how you can use real time location information to help protect your patients or residents and automate staff workflows.



**Secure
Care**
Products, LLC

For more information on our products visit us at:

www.securecareproducts.com

39 Chenell Drive, Concord, NH 03301-8501
603-223-0745 or 800-451-7917
info@securecare.com



Made in the USA Meets UL Standards ISO 9001 COMPLIANT FC ETL CE

Secure Care Products LLC
39 Chenell Drive
Concord, NH 03301
p: 1.800.451.7917
p: +1.603.223.0745
f: +1.603.227.0200
e: info@securecare.com
w: www.securecare.com
P/N: P05280690 REV H 8/30/2016